

Service Manual

Track excavator

1404



Machine model	1404
Edition	1.1
Language	English
Item no.	1000166693

Documentation

Description	Order no.
Operator's Manual	1000164553
Service manual	1000166693
Spare parts list	1000163718

Copyright – 2006 Neuson Baumaschinen GmbH, Linz-Leonding

Printed in Austria

All rights reserved

No part of this publication may be reproduced, translated or used in any form or by any means – graphic, electronic or mechanical including photocopying, recording, taping or information storage or retrieval systems – without prior permission in writing from the manufacturer.

The cover features the machine with possible optional equipment.



Neuson Baumaschinen GmbH

Haidfeldstrasse 37

A-4060 Linz-Leonding

Document: SERV-HB 1404 EN

Order no.: 1000166693

Edition: 1.1



Table of contents

Operation	1
Important information on this service manual	1-1
Abbreviations/symbols	1-1
Identification of warnings and dangers	1-2
Designated use and exemption from liability	1-3
Type labels and component numbers	1-4
Machine overview	1-6
Cab overview	1-7
Cab overview: legend	1-8
Instrument panel overview	1-9
Instrument panel overview: legend	1-10
Engine compartment: overview	1-11
Chassis overview	1-12
Removing the cab	1-13
Removing the cab	1-14
Removing the floor panel	1-14
Battery master switch (model 1404)	1-14
Specifications	2
Chassis	2-1
Engine	2-1
Fuel injection pump	2-2
Engine capacities	2-2
Engine tightening torques	2-2
Hydraulic system	2-2
Auxiliary hydraulics oil flow	2-2
Work hydraulics	2-3
Undercarriage and swivel unit	2-3
Stabiliser blade	2-3
Electric system	2-3
Fuses on left-hand side control lever base	2-4
Main fuse box with relays	2-4
Noise levels	2-4
Vibration	2-5
Coolant compound table	2-5
Model-specific tightening torques	2-5
General tightening torques	2-6
Tightening torques for hydraulic screw connections (dry assembly)	2-6
Tightening torques for high-resistance screw connections	2-8
Dimensions model 1404	2-9
Lift capacity table 1404 RD	2-10
Lift capacity table 1404 RD with long stick (option)	2-11
Lift capacity table 1404 RD with cab (option) and telescopic undercarriage (option)	2-12
Lift capacity table 1404 RD with cab (option), long stick (option) and telescopic under-	
carriage (option)	2-13
Kinematics	2-14
Attachments	2-15
Maintenance	3
Fluids and lubricants	3-1
Additional oil change and filter replacement (hydraulics)	3-2
Maintenance label	3-3
Explanation of symbols on the maintenance label	3-3
Maintenance plan (overview)	3-5



Service package	3-8
Introduction	3-8
Fuel system	3-9
Specific safety instructions	3-9
Refuelling	3-9
Stationary fuel pumps	3-10
Diesel fuel specification	3-10
Bleeding the fuel system	3-10
Emptying the fuel tank	3-11
Fuel prefilter with water separator	3-12
Replacing the fuel filter	3-12
Engine lubrication system	3-13
Draining engine oil	3-14
Filling up engine oil	3-14
Changing engine oil	3-15
Replacing the engine oil filter cartridge	3-16
Engine cooling system	3-17
Specific safety instructions	3-17
Checking/filling up coolant	3-18
Draining coolant	3-19
Air filter	3-20
Air intake	3-20
Filter replacement	3-21
V-belt	3-22
Checking V-belt tension	3-22
Tightening the V-belt (dynamo)	3-23
Tightening the V-belt (alternator)	3-24
Pressure check	3-25
General	3-25
Checking pilot control pressure	3-25
Pressure check of gear pump P	3-26
Secondary pressure limiting valve of the gear motor	3-26
Test report	3-27
Hydraulic system	3-29
Specific safety instructions	3-29
Checking the hydraulic oil level	3-30
Filling up hydraulic oil	3-31
Changing hydraulic oil	3-31
Important information for the use of biodegradable oil	3-32
Checking hydraulic pressure lines	3-33
Pilot control filter (from serial number AF01441)	3-34
Travelling drive	3-35
Checking the oil level and filling up oil	3-35
Draining oil	3-35
Chains	3-36
Checking chain tension	3-36
Setting the chains	3-37
Lubrication work	3-38
Lubrication points on the stabiliser blade	3-38
Lubrication points on the swivelling console	3-38
Boom lubrication points	3-39
Lubrication points on the stick	3-39
Lubrication point for offset ram	3-39
Lubrication point on the live ring	3-40
Maintenance of attachments	3-40
Electric system	3-41
Specific safety instructions	3-41



Service and maintenance work at regular intervals	3-41
Instructions concerning specific components	3-42
Alternator	3-42
Battery	3-43
General maintenance work	3-44
Cleaning	3-44
General instructions for all areas of the machine	3-44
Inside the cab	3-45
Cleaning the seat belt	3-45
Exterior of the machine	3-45
Engine compartment	3-45
Screw connections and attachments	3-46
Pivots and hinges	3-46
Engine	4
3TNV76-SNS2 engine overview	4-1
Fuel system	4-3
Checking and adjusting valve tip clearance	4-4
Tightening order for cylinder head bolts	4-4
Checking the injection nozzles	4-5
Pressure check	4-5
Checking the nozzle jet	4-5
Injection time	4-6
Checking and adjusting injection time	4-6
Replacement of fuel injection pump	4-7
Adjusting engine revs	4-8
Compression	4-8
Checking the coolant thermostat	4-8
Checking the thermal switch	4-9
Oil pressure switch	4-9
Checking the coolant circuit	4-10
Engine trouble	4-10
Hydraulic system	5
Gear pump AZPS-11-014RRR20MB	5-1
Pump unit: exploded view	5-2
Pilot oil supply unit	5-3
Main valve block SX 10	5-4
Ports	5-4
Legend	5-5
Sectional view	5-6
Functional description	5-6
Possible configurations	5-7
Main valve block diagram	5-8
Pressure limiting valves	5-9
Load sensing	5-10
Auxiliary hydraulics connections	5-10
Pilot valves	5-11
Joystick	5-11
Travelling drive	5-12
Function	5-12
Swivel unit	5-14
Swivel unit overview	5-18
Swivel joint	5-19
Sealing	5-20
Mechanical controls	5-20
Breather filter	5-22



Troubleshooting in the hydraulic system	5-23
Hydraulics diagram A4	5-24
Hydraulics diagram: legend	5-25
Hydraulics diagram 1404 RD	5-27
Main valve block diagram 1404 RD	5-28
Electric system	6
Ohm's Law (current, voltage, resistance); power	6-1
Measuring equipment, measuring methods	6-1
Cable colour coding	6-2
Relays	6-3
Use, mode of function	6-3
Electric system	6-3
Fuses on left-hand side control lever base	6-3
Main fuse box with relays	6-4
Instrument panel overview	6-4
Dynamo and governor	6-5
Starter	6-5
Wiring diagram A4 1404 RD: legend	6-7
Wiring diagram A4 1404 RD	6-8
Engine wiring harness 1404 RD: legend	6-9
Engine wiring harness A4 1404 RD	6-10
Seat console wiring harness A4 1404 RD: legend	6-11
Seat console wiring harness A4 1404 RD	6-13
Alternator wiring harness (option) A4 1404 RD	6-14
Wiring diagram A3 1404 RD: legend	6-16
Wiring diagram A3 1404 RD	6-17
Engine wiring harness A3 1404 RD: legend	6-18
Engine wiring harness A3 1404 RD	6-19
Seat console wiring harness A3 1404 RD: legend	6-20
Seat console and alternator wiring harness (option) A3 1404 RD	6-21
Options	7
Long stick	7-1
Specifications	7-1
Drive interlock (antitheft protection)	7-1
Position	7-1
Programming	7-1

Operation

1 Operation

1.1 Important information on this service manual

This service manual contains important information on how to work safely, correctly and economically with the machine. Therefore, it aims not only at new operators, but it also serves as a reference for experienced ones. It helps to avoid dangerous situations and reduce repair costs and downtimes. Furthermore, the reliability and the service life of the machine will be increased by following the instructions in the service manual.

Careful and prudent working is the best way to avoid accidents!


Operational safety and readiness of the machine do not only depend on your skill, but also on maintenance and servicing of the machine.

Insist on using original spare parts when carrying out maintenance and repair work. This ensures operational safety and readiness of your machine, and maintains its value.

Your Neuson After-Sales Service will be pleased to answer any further questions regarding the machine or the service manual.

Abbreviations/symbols

- This symbol stands for a list
 - Subdivision within lists or an activity. Follow the steps in the recommended sequence

 This symbol requires you to carry out the activity described

 Description of the effects or results of an activity

n. s. = not shown

“Option” = optional equipment

Stated whenever controls or other components of the machine are installed as an option.

A combination of digits, or a combination of digits and letters, e.g. 40/18 or 40/A used for identifying the control elements, means:

Figure no. 40/control element no. 18 or position **A** in figure no. 40

Figures carry no numbers if they are placed to the left of the text.


1.2 Identification of warnings and dangers

Important indications regarding the safety of the staff and the machine are identified in this service manual with the following terms and symbols:



Danger!

Failure to observe the instructions identified by this symbol may result in personal injury or death for the operator or other persons.

 *Measures for avoiding danger*



Caution!

Failure to observe the instructions identified by this symbol may result in damage to the machine.

 *Measures for avoiding danger for the machine*



Important!

This symbol identifies instructions for a more efficient and economical use of the machine.



Environment!

Failure to observe the instructions identified by this symbol may result in damage to the environment. The environment is in danger if environmentally hazardous material (e.g. waste oil) is not subject to proper use or disposal.

THANK YOU FOR VISITE WITH

www.repair-manuals.com

DOWNLOAD THIS FULL MANUAL

Until download and place it on your computer We care with you ,We really try our best to complete your orders, so your review is very important to us to improve our services

WE OFFER

ORIGINAL FACTORY MANUALS , WORKSHOP
MANUALS , SERVICE MANUALS , REPAIR

OUR VISION : 100 % CUSTOMER SATISFACTION,
AFTER SALE SERVICE AND KEEP IN TOUCH WITH